

## Cement Anchor Installation Instructions

1. Drill a hole into the ground narrow enough for the anchor body to fit tightly (see table for bit reference) and a depth shallow enough for at least one-third of the threaded area to be above ground.
2. Insert the anchor bolt head-first and halfway down, then insert the sleeve over the anchor bolt, flare-side down.
3. Partially screw in the product onto the anchor bolt.
4. Push the product all way down and continue to screw in until the anchor is tight.

Part Number	Bit Size
DSF600	5/8"
DSF630	5/8"
DSF444	3/8"
FDB278	3/8"
FDB218	3/8"

